Use the following pipeline to execute the following sequence of instructions, when the sw instruction reaches the memory stage. List the value on all labeled wires, assuming register contains 100+(register number):

sw $9, 12($10)
addi $7, $8, 5